

## **INSTALLING THE CABLE GUIDE**

Sun Guardian, Sun Out and Soltis Shades

### **Parts List (pre- assembled)**

- 2 Cables with Copper Fittings secured to each end – (a crown bolt and nut affixed to each)
- 2 Cable Guides (already installed on each cable)
- 2 Bottom Aluminum L Brackets each attached to a Copper Fitting with Set Screws

### **Tools Required**

- Electric Drill
- Flat Screw Driver
- Wire Cutter

### **Installation Instructions**

1. Install the Rollease shade brackets into the mounting surface making sure they're level
2. Unscrew the nuts from the top copper fitting (the end opposite the L bracket) and bolt each fitting into the bottom inside hole of each shade bracket, tighten nuts.
3. Install the shade securely into the brackets
4. Remove the nylon end pieces from the aluminum weight bar on bottom of the shade and insert the cable guides.
5. Plumb the cable wire so the bottom brackets are in line
6. Screw the bottom brackets into the floor or wall with a drill
7. Loosen the screws in the bottom copper fitting, pull the cables tight and tighten set
8. Tighten nuts so copper stops remain fixed in place
9. Cut excess cable
10. Operate shade – it must ride on the cables without binding
11. When the shade is down you can also use the D rings for added protection

**Cable Guides control the movement of the Bottom Bar  
Do not use shades during moderate or high wind conditions**