

**Solar-Screen
Cable Guide System**
Fixed Guide on Bottom Bar
Flat Eye or Screw Eye secures cable vertically

Parts List

1. Fixed Guides are secured to the bottom bar.
2. (4) Flat Eye Screws & 8 Installation Screws
3. (4) Eye Screws
4. (2) Cables with Copper Stop secured to one end.
5. (2) Cable Stop with Screw

Tools

1. Electric Drill
2. Screw Driver
3. Pliers
4. Pencil
5. Wire Cutter (optional)

Installation Instructions

1. Install Solar-Screen shade and confirm it is rolling up and down correctly.
2. Roll shade up leaving about 4 inches of material showing below the roller.
3. Install **Top Guides** (Flat Eye Screws or Eye Screws) **ABOVE** the Bottom Bar Guide approximately in line.
4. Roll shade down stopping about 2 inches from bottom or lower if space permits.
5. Install **Bottom Guides** (Flat Eye Screw or Eye Screws) **BELOW** the Bottom Bar Guide approximately in line.
6. **Feed cut end of Cables** through the Top Guide & Bottom Bar Guide & Bottom Guide.
7. Slide **Screw Lock Bottom Cable Stop** on Cable below Bottom Guide.
8. **Pull Cable tight** with Pliers and tighten Screw.
9. Cut excel cable to tuck out of the way.
10. Operate shade-it must ride on side cables without binding.
11. When shade is fully down also use the **Bottom Bar Tie Downs**.

Cable guides control movement of Bottom Bar
Do not use Shades during moderate or high wind conditions



Bottom Bar Guides

Two removable screws secured Guides to right and left side of the bottom bar.

(4) Flat Eye Screw Guide
In line with Bottom Bar Guides
Installs top and bottom
horizontals to side walls
Or Use Eye Screws.

