

Resetting Limit Stops for Hardwired Shades (If Motors are Already Working)

A test cable is not needed since the wiring is done and the motors are already working. Limits are set without removing the shade from its brackets.

There is a yellow cap on the motor side.

Remove the cap by prying up. No Pressure is needed.

Inside there are two buttons that are presently depressed which are the Up and Down travel limits. (When depressed the limits are set.)

You need to know which is the “Up” and which is the “Down” button. It’s easiest to press one button and it will pop out. Press and release the up direction of the switch that controls the shade. If the shade moves up this is the upper limit stop. Then power the shade to the new height and depress the button to reset the travel limit.

It is important that the operating switch be touched and the shade watched as it moves. Without the limits the shade will continue to lift and can jam into the brackets or even pop the shade out. Or if the shade is rolling down it can go too far and pull the material off the roller. The roller turns relatively slowly at 32 turns per minute but care must be taken at this step.



Customer Service:

Toll-Free Order Line:(866) 230-4700

If Local to Massachusetts, call 978-470-8082

Fax: (978) 475-6496

E-mail: sales@northsolarscreen.com

Address:

North Solar Screen, LLC

9 Bartlet Street,

Suite 231

Andover, MA. 01810